



## Stahováky s tuhými čelistmi

Serie 1010H

Hydraulický stahovák 8 tun


K utahování pomocného vřetena nepoužívejte klíče ani páky.  
Viz pokyny k vřetenu strana 50.



Ref.	A	B	C	F	Tm.	P	⚖️	🔧
1010H	160	150	210	150000E	8	1	4,5	101050
1010LH	220	150	210	150000E	8	2	5,4	101060
1010AH	160	195	260	150000E	8	1	5,1	101050
1010LAH	220	195	260	150000E	8	2	5,8	101060

## Serie 1012H

Hydraulický stahovák 12 tun




Utáhněte pomocné vřeteno klíčem č.17. Viz pokyny k vřetenu strana 50.

Ref.	A	B	C	F	Tm.	P	⚖️	🔧
1012H	160	150	210	150120	12	1	4,5	101050
1012LH	220	150	210	150120	12	2	5,4	101060
1012AH	160	195	260	150120	12	1	5,1	101050
1012LAH	220	195	260	150120	12	2	5,8	101060

## Serie 1016H

Hydraulický stahovák 16 tun

Utáhněte pomocné vřeteno klíčem č.17. Viz pokyny k vřetenu strana 50.



Ref.	A	B	C	F	Tm.	⚖️	🔧
1016H	160	250	345	101683	16	12,5	102050
1016LH	290	250	345	101683	16	15,5	102060
1016AH	160	390	475	101683	16	15,5	102050
1016LAH	290	390	475	101683	16	17,0	102060
1016XH	160	600	675	101683	16	22,0	102055
1016XLH	290	600	675	101683	16	25,0	102065